

HERTRON STONE SYSTEMS

PRIME GRIND FORMULA



2

A component of the HERTRON PRIME GRIND System, which completes the chemical hardening process in the surface pores of the stone

DIRECTIONS: May be applied by either of two equally effective methods. It may be used as the grinding liquid in the final grinding pass diamond pads by mixing 1 part PRIME GRIND 2 with 4 parts water. Remove residue with wet vac and damp mop. The second method is performed after all grinding has been completed, the stone is rinsed and wet vacuumed dry and allowed to dry over night if possible. PRIME GRIND 2 is then misted onto the stone and burnished until dry with #0 steel wool pad (or hair pad). This is done with a low speed weighted buffing machine. Coverage 2000 to 3000 sq. ft. per gallon.

WARNING: CORROSIVE

Avoid breathing of fumes. Maintain adequate ventilation. May cause skin, eye and mucous membrane irritation. If in contact with skin, flood with water for 10 minutes; wash with soap. If in contact with eyes flush with water for 15 minutes, If ingested, drink several glasses of water and induce vomiting; call physician.

WARNING: CORROSIVE

HMIS Rating
: Health:3; Flammability: 0; Reactivity:1

HERTRON STONE SYSTEMS

**HERTRON INTERNATIONAL, LLC.
CHARLOTTE, NC 1-800-438-5066
MADE IN USA**